

Beverly Clock Instructions



Beverly Clock Instructions

Starting a new game

1. Press [NEW GAME] then [CLEAR]
2. Press '1' for timer direction down
3. Press [ENTER] If period is OK
4. Press [ENTER] If minutes is OK
5. Press [ENTER] If seconds is OK
6. Press [ENTER] If 1/100 seconds is OK

Timer Operations

1. Game [TIMER RUN] to start
2. Game [TIMER HOLD] to stop
3. [SET TIMER] to correct Game Time
4. When Period is finished, press [PERIOD] to advance to the next one

Intermission/Warm Up

1. Press [INTER-MISS], to switch to Intermission/warm up
2. Press TIMER RUN/HOLD to start/pause intermission timer
3. To END INTERMISSION/WARMUP, press [RECALL] [INTER-MISS], then enter a time of 0:00

Scoring

1. Press [SCORE] (either HOME or GUEST)
2. For corrections, press [RECALL], [SCORE] and enter a corrected score

Penalties

1. Press [PENALTY] (Home or Guest)
2. Press [ENTER] for normal penalty or ALT PEN for delayed penalty or misconduct
3. Enter player number and press [ENTER]
4. Enter penalty minutes and press [ENTER] (or Just [ENTER] for default)
5. Enter penalty seconds and press [ENTER] (or just [ENTER] for default)
6. To cancel a penalty after a power-play goal, press [RECALL], [PENALTY] (Home or Guest), [CLEAR], [ENTER]

Displaying Time of Day on Scoreboard

1. Press [RECALL], [TIME OF DAY] to switch to Time of day display
2. Press [RECALL], [SET TIMER] to switch back to Game Timer display

Entry of Team Names

1. Press [TEAM NAMES] (Home or Guest)
2. Pressing a key on the numeric keypad cycles through a set of letters accessible with that key
3. Press '+' to advance to the next character, '-' to go back
4. Press [ENTER] when finished
5. When starting a new game, press [RECALL], [TEAM NAMES] to display the last entered name