Time Button

Set Button

Time Clock Start /Stop

Yes Button

Penalty Clear Button

Home Penalty Button

Guest Penalty Button

Home Score Button

Guest Score Button

Horn Button Normally not used

Model Code 871

Horn

Misc.

Set

Penalty Insert

Time

Penalty On Off

Penalty Clear

Time On

Home Goal

Home Penalty

Home Shots

Time Off

Guest Goal

Guest Penalty

Guest Shots

Time Out Timer

Start   Clear

Options

Yes   Confirm

7   8   9

No   Cancel

4   5   6

Chronometer (Time of Day)

1   2   3

Home Score

Blank   0

Guest Score

Nevco Scoreboard Compa... ...0 USA / 800-461-8550 Canada

www.n...   ...rds.com

Operating instructions ar... ...e back side of this overlay

Clock/Score

Set Clock- SET/TIME/
Enter Digits(ex 12 minutes = 1-2-0-0)/
Press YES
The display will ask period? Enter 1, 2, 3, or 4 for correct period

Set Score- Press HOME SCORE then 1. Repeat for each goal scored.

Correcting Score- SET/HOME SCORE/
Enter correct digit(s)/YES

Penalty

Set Home Penalty- SET/HOME PENALTY/
Enter Digits (ex 0130 for 1:30)/
YES/Enter Digits for Player #.

Player's # is always 2 digits (ex. 8 enter as 08

Clear Penalty- HOME PENALTY (until the correct penalty is on the display)/
PENALTY CLEAR/
the display will read CLEAR (Y-N)
Press YES.