Rushmore Hockey Association

Ice Management

Ice Resurfacing

- Resurface prior to practice or game with hot water.
- Use cold water following practices for Bantams, Boys JV/Varsity, and Girls.
- Resurface between periods for Boys and Girls Varsity / Boys JV.
- Resurface after 2nd period for Girls JV and below.
- Resurface after last practice or game of day.
- Use cold water wash for deep gouges and for Bantams and up.
- Do <u>NOT</u> skate on dirty ice following Boys Varsity. This is <u>NOT</u> acceptable.
- Current RHA Olympia Policy is posted on the website: http://www.rushmorethunder.com/files/Documents/Ice_Policy.pdf
- Each team will need to assign 2 operators to run the Olympia. The team taking the ice will need to resurface prior to practice.
- Each team will need to cover their own practices and is responsible to cover games and other league games.
- The last team of the day is also responsible to resurface the ice after practice.
- Individual training sessions can be set up any time by calling Ted Schultz at 381-0433 or Roger Hall 390-8413.
- Raise the conditioner (blade) before the gate and stop. Stop with your wheels on the ice.
- Turn off zam water on the last blue line NOT at gate. Use squeegee if you have water.
- Use practice nets for practice. Push the nets out of the way so we can use the gates. Game nets <u>MUST</u> be placed by the Compressor Room door.
- Shovel the snow off the ice and off the concrete area outside the gate. The snow <u>MUST</u> be removed from the concrete area and shoveled outside and through the garage door.
- Chip ice off the threshold and gate area. Drill peg holes out for the gate.
- Do <u>NOT</u> ride the boards or hit the boards in any way. This is not acceptable.
- Do <u>NOT</u> run Bleacher Heat during practices for Squirts, Peewees, Bantams, B/G JV/Varsity.

- Do <u>NOT</u> run Bleacher Heat if the outside temperature is 55 degrees or higher.
- Use cold wash waster following practices for Bantams, Boys JV/Varsity and Girls JV/Varsity.
- The last team of the day is also responsible to resurface the ice after practice.
- Teams <u>MUST</u> get off the ice at the scheduled time. We have limited time to zam and every team deserves their full practice time.
- The morning practice team is responsible to zam after the morning practice prior to the next scheduled practice that day.
- The north goal crease (blue area) is historically thin ice. Put additional full water layers over the north goal crease when you are complete with ice resurfacing.
- Do <u>NOT</u> drive in the mud. Stay on the gravel. Build a snow road to the west end for snow dump. Do NOT dump snow at the end of the concrete on the west side.
- If you break glass. Call Ted Schultz 381-0433. Spare glass is in Mechanical Room 1. Drills and screws are in the Zam garage. Clean up glass and put in the green dumpster.
- It is ok to lower the Olympia blade. If you are not cutting make sure the conditioner is down and turn the blade clockwise in ¼ turn increments until cutting.
- Do not move the Olympia in or out of the garage until the doors are up 100%.
- If you are going to hit the boards: Stop! Shut off Water! Raise Conditioner! Back up. Turn and proceed. Make a pass over the snow/flooded area to clean up.
- Only trained and approved drivers are to operate the OLYMPIA.
- Do not zam the first pass with the doors open unless you are the only one at the rink.
- Do not run Bleacher Heat during practices for Squirts, Peewees, Bantams, B/G JV/Varsity. Once the rink temp is between 45-48 Degrees F it will the ice will not freeze within the 15 minute zam time.
- Do not run Bleacher Heat if the outside temperature is 55 degrees or higher.
- Read the Olympia Ice Resurfacing Guidelines.