

# SCOREBOARD INSTRUCTIONS

NHL & OLY Rinks at USA Hockey Arena

## **Turn on Scoreboard (switch on back of console)**

Enter code: 63

Press ENTER

Press ENTER again for the 10ths of a second mode or  
CLEAR for non-10ths mode.

Push SET TIME

Enter time

Push ENTER

## **To Enter Score**

Push SCORE +1 on either guest or home

If you make a mistake, push ●SCORE and enter correct  
number of goals, push ENTER

## **To Enter Penalties**

Push PENALTY arrow

Push ●PLAYER ●PENALTY

Push ENTER

Enter PLAYER NUMBER

Push ENTER

Enter PENALTY TIME

Time and number will now appear in the penalty section.

## **To Clear Penalties**

Push ●PLAYER ●PENALTY

Push Up Arrow above MENU button to select penalty

Push CLEAR

Push ENTER

## **To Stop & Start Time**

Press START button to start time

Press STOP button to stop time

**Please turn the console off when you're done! ☺**