

# OIC SCOREBOARD OPERATION



## To Turn On the Scoreboard

- Turn the rocker switch (back left of controller) to "ON" position.
  
- *If scoreboard does not light up, make sure Master Switch (#4 fuse in the electrical panel) in Compressor Room is ON – see rink manager.*

## To Enter the Score

1. Press: the "**Home Score**" or "**Visitor Score**" key
2. Enter the score (**Use Numeric Pad**) (0,1,2,3...)
3. Press the "**Enter**" key

## To Set the Time for the Period

1. Press the "**Set Clock**" key
  - a) Press one time **ONLY!** This enters "Clock" mode
2. Enter time (**Use Numeric Pad**)
  - a) Enter 4 digits, with a leading "0" for times less than ten minutes
  - b) e.g. 0800 for 8 minutes; 1200 for 12 minutes
3. Press the "**Enter**" key

## To Set the Period

1. Press the "**QTR, Period, Half**" key
2. Enter period (**Use Numeric Pad**) **1, 2 or 3**
  - a) Enter 1, 2, or 3 for standard periods
  - b) Enter 4, 5, 6... for overtime periods
3. Press: "**Enter**" key

## To Enter a Penalty

1. Press the "**Home Penalty**" or "**Visitor Penalty**" Key
2. Press one of the **preset penalty buttons**:
  - a) "**-1**" key for 1:30 min. penalty (minor 12 for minute period)
  - b) "**+1**" key for 2:00 min. penalty (minor for 15-20 minute periods)
  - c) "**+2**" key for 4:00 min. penalty (double-minor or major for 12 minute period)
  - d) "**+3**" key for 5:00 min. penalty (major for 15-20 minute periods)
3. **Enter the player's Jersey number (Use Numeric Pad)**
  - a) If the number is less than 10, enter leading "0"
  - b) e.g. 08 for a jersey numbered 8; 12 for a jersey number 12
4. Press the "**Enter**" key
  - Repeat steps 1-3 if a second penalty occurs while the first penalty is still running. Make sure to use the correct jersey numbers!

## To Clear a Penalty

1. Press the "**Home Penalty**" or "**Visitor Penalty**" Key
2. Press the "**CLR**" Key
3. Enter the player's Jersey number (**Use Numeric Pad**)
  - a) This must be the same as the # used to enter penalty
4. Press the "**Enter**" Key
5. Press the "**CLR**" Key
6. Press the "**Enter**" Key

## To Hold a Penalty Over to the Next Period

1. Press the "**Set Clock**" key **2 TIMES!!!** (this enters "Break" mode)
2. Enter time for break between periods (**Use Numeric Pad**) - Enter 4 digits, with a leading "0"
  - a) 0100 for 1 minute (between 12 minute periods); 0200 for 2 minutes (between longer periods)
3. Press the "**Enter**" key ( the Clock will run down but Penalties will not)
4. When the horn sounds, reset the clock for next period (press "**Set Clock**" key **ONLY** once!!)