

Power switch located on back of unit

Setting Time

- Clock set
- Minutes desired (enter 0500 for 5 minutes, 15 for 15 minutes, etc.)
- Enter

Setting Period

- Period
- 1, 2, 3 or 4
- Enter

Entering Goals

- 'Home Score' or 'Visitor Score'
- +1

Entering Penalties

- 'Home Penalty' or 'Visitor Penalty'
- +1 for a 2 minute penalty or +2 for a 5 minute penalty
- Always enter #1 for player number. If two penalties, second one use #2
- Enter

Entering 1:30 Penalties

- 'Home Penalty' or 'Visitor Penalty'
- +1 for a 2 minute penalty or +2 for a 5 minute penalty
- Always enter #1 for player number. If two penalties, second one use #2
- Enter
- 'Home Penalty' or 'Visitor Penalty'
- Hit Clear
- #1 (assuming you entered #1 when you entered the penalty) or #2 if that one
- Enter
- 1:30 for new time
- Enter

Clearing Penalties

- 'Home Penalty' or 'Visitor Penalty'
- Hit Clear
- #1 (assuming you entered #1 when you entered the penalty)
- Enter
- Hit Clear again
- Enter

To Clear the Scoreboard

- Press and hold the shift key and press the 'New Game' key
- Yes