

## **TIME CLOCK INSTRUCTIONS**

### **POWER UP / DOWN**

Press the POWER key to turn on the LAX Clock. When first turned on a short diagnostic will execute to allow verification of the LCDs, LEDs & Horn. All LCDs will display 8.8:8.8 and all LEDs will illuminate for a short time. To turn the LAX Clock off press the POWER key.

### **RESET KEY**

If the LAX Clock ever enters some unknown state, press the RESET key to initiate a reset cycle and may help the LAX CLOCK recover.

### **MODE KEY**

This key controls the type of alarm emitted by the clock's Timer. On power up the timer's alarm defaults to loud & is indicated by the blinking GAME LED. This type of alarm can be used to signal the end of the half or game. If desired you can switch the type of to soft by pressing the MODE key. When this alarm type is selected the timer PENALTY LED will be blinking.

### **KEEPING SCORE**

The outer two PENALTY timers allow the timer keeper to also track team scores. Press the SCORE key to activate the scoreboard mode. Once in scoreboard mode VISITOR & HOME score is changed by pressing the + key and – key the scores. To exit the SCORE board mode and resume time keeping press the SCORE key again

### **ENTERING TIMES**

Press the SET / CLEAR key to select the Timer that will receive the inputted time, the LAX CLOCK will illuminate the associated LED. Enter the desired countdown time via the numeric keypad & press the SET / CLEAR key to exit the time entry mode.

**EXAMPLE** - Enter 30 sec. PENALTY time, 10 Min. GAME TIME and start clocks running:

- 1 - Press left PENALTY timer's SET / CLEAR key, observe its associated LED illuminates.
- 2 - On the numeric keypad press 3 followed by 0.
- 3 - Press GAME CLOCK timer's SET / CLEAR key, observe its associated LED illuminates & PENALTY timer LED extinguishes.
- 4 - On the numeric keypad press 1 followed by 0,0,0.
- 5 - Press ALL CLOCKS key to start both timers running.

### **STARTING / STOPPING TIMERS**

**STARTING** - Press ALL CLOCKS key or PENALTY CLOCKS key, will start any halted timer with count down time remaining.

### **STOPPING - Timers for RUNNING Game Clock**

Pressing the START/STOP PENALTY CLOCKS key will stop the outer two PENALTY timers from counting down while the center timer will continue counting down. Use this key for games that require a Running Game Clock.

**RESETTING** - To reset a timer to 0 and stop it from counting down as specified above, press the timers associated SET / CLEAR key.

### **RESETTING / SOUNDING THE ALARM**

**RESETTING** - When a timer reaches 0 it will sound the alarm and blink the red LED located to the right of the display. Resetting an alarm condition for any timer is accomplished by pressing the HORN CLEAR key located on the left side of the LAX Clock.

### **SOUNDING**

**ALARM** - To turn on the internal HORN, press the HORN ON key. To turn the internal HORN OFF, press the HORN CLEAR key.