

## SCOREBOARD BASICS 2024-25



### Start a Game: (Red)

1. Select Game Time
2. Select 1-7 then ENTER – then ENTER at each set of 00's. Time should display.
  - a. (Varsity and JV 17 minutes, MS 16 minutes, Youth 13 minutes)

### Game Play:

1. Select Run to run the clock.
2. Select Stop to stop the clock.

### Enter a Goal: (Purple/Yellow)

1. Select Home Score +1.
2. Select Guest Score +1.  
(To manually update a score hit Home/Guest score – ENTER -then number- ENTER)

### Enter a Penalty: (Purple/Yellow)

1. Select Home/Guest Pen – ENTER
2. Select Player number (this does not display on board)
3. Select 0-2 (Minute) – Enter at 00 (Seconds) on readout - ENTER again.  
(for Youth 0-1 – ENTER select 30 – ENTER)
4. Add additional penalties same way – should move to next readout.

### Clear a Penalty: (Purple/Yellow)

1. Select Home/Guest Pen until display goes back to original penalty.
2. Select CLEAR then ENTER. (The penalty should be gone from the scoreboard).

### Periods: (Green)

1. Select Period
2. Select 1, 2 or 3.
3. Select ENTER.