

# SET UP

- Plug Clock In
  - Turn Clock On (bottom right hand side)
  - Do you want to start where you last turned off? **NO**
  - Model **#871**
  - Operate wirelessly? **YES**
  - Basketball? **NO**
  - Hockey? **YES**
  - Use Penalty? **YES**
  - Will display 00:00
- 

## TURNING OFF THE CLOCK

- Hit **SET** on the left hand side, then **CHRONOMETER**
- Do you have an auxiliary? **YES**
- Display Chronometer? **YES**
- Enable Chronometer? **YES**
- Set Chronometer? **NO**
- Display Chronometer? **YES**
- Leave Chronometer displayed but turned off? **YES**
- Put back in case, return to front desk (**IF YOU ARE THE LAST GAME OF THE MORNING**)

# CHEAT SHEET

## SET GAME TIME

- SET - TIME - 0,5,0,0 (for warmup) 1,2,0,0 (for squirt through bantam divisions)
- YES - 1,2 or 3 for Period - YES

## GOALS SCORED

- stop the clock
- SET - HOME SCORE/VISITOR SCORE - 1 - YES

## PENALTIES

- stop clock
- SET - HOME PENALTY/GUEST PENALTY - 0,1,3,0 - (enter players jersey number, make sure there is a 0 before a single digit jersey number E.G. 02 for #2)
- To stop the penalty clock from running during periods, push the Stop Penalty Time on left side of time clock board.

## CLEAR PENALTY

- Press HOME PENALTY/VISITOR PENALTY until you reach the right penalty
- PENALTY CLEAR - YES

## CORRECT SCORE AFTER MISTAKE

- stop clock
- SET - HOME SCORE/GUEST SCORE
- enter correct score - YES

## BETWEEN PERIODS

- set clock time for ONE MINUTE between periods unless told otherwise by an official