

Clock Instructions

Start up:

- 1. Turn power switch **ON**
- 2. At the **Resume Game? Y/N** prompt:
- 3. Press **<Enter/Yes>** to resume the game where last shut off

Setting Clock for Period:

- 1. <Set Main Clock>
- 2. Put in time i.e.1500
- 3. Press **<Enter/Yes>**
- 4. Press **<Enter/Yes>**
- * Make sure time is up on main clock
- * **<Start>** to start, **<Stop>** to stop

Score: *Must select in Home or Guest field*

- 1. **<Score +1>** for Home or Guest
- 2. To adjust scores, press **<Score•>**, press the number of goals to display, then press **<Enter/Yes>**

To Clear Scores:

- 1. <Score•>
- 2. **<Clear/No>**
- 3. **<Enter/Yes>***Do this for each team

Penalty: Must select in Home or Guest field

- 1. <Player Penalty>
- 2. Press <Enter/Yes>
- 3. Enter Player #
- 4. Press < Enter/Yes>
- Enter "130"-for 1:30 penalty, "500" for 5:00 penalty OR <Enter/Yes>
 Enter/Yes>-for 2:00 penalty, this is the default penalty time in controller
- *Clock automatically starts and stops penalty time
- ** Between periods, press **< Disable Penalty Clocks>** to keep penalty time on the board from counting down.
- *** At start of next period, be sure to press **<Enable Penalty Clocks>** to keep penalty time moving.

Clear Penalty Clock

- 1. < Player Penalty>
- 2. Go up one level, < Menu ^>
- 3. **<Clear/No>**
- 4. **<Enter/Yes>**

Change Period:

- 1. "Period+"
- 2. "Clear"
- 3. "Enter"

