

SCORE CLOCK INSTRUCTIONS – BOTH RINKS

1. POWER ON MACHINE. (SWITCH ON RIGHT SIDE)

IT WILL ASK IF YOU WANT TO START WHERE YOU LEFT OFF LAST?

PRESS KEYPAD **NO**

IT WILL ASK IF YOU WANT TO GO TO A BOOKMARK?

PRESS KEYPAD **NO**

ENTER MODEL CODE # OF MACHINE

PRESS KEYPAD NUMBERS **871**

IT WILL ASK YOU IF YOU WANT PENALTY TIME OUT? YES / NO

PRESS KEYPAD **YES**

2. TO SET TIME

NOTE: THIS STEP IS REPEATED AT THE BEGINNING OF EACH PERIOD

PRESS KEYPAD **SET**

PRESS KEYPAD **TIME**

{ENTER TIME ie. 12:00 min period}

PRESS KEYPAD **1**

PRESS KEYPAD **2**

PRESS KEYPAD **0**

PRESS KEYPAD **0**

PRESS KEYPAD **YES**

IT WILL ASK FOR PERIOD

PRESS KEYPAD **1,2 OR 3** (Depending on what period it is.)

3. TO START CLOCK

AT THE DROP OF THE PUCK

FLIP THE SWITCH ON THE HAND HELD CONTROL TO **“ON”**

TO STOP THE CLOCK FROM RUNNING TIME

FLIP THE SWITCH ON THE HAND HELD CONTROL TO **“OFF”**

4. TO SET SCORE

SET THE SCORE TO ZERO FOR BOTH TEAMS AT THE BEGINNING OF THE GAME

PRESS KEYPAD **SET**

PRESS KEYPAD **HOME SCORE**

PRESS KEYPAD **0**

PRESS KEYPAD **YES**

PRESS KEYPAD **SET**

PRESS KEYPAD **GUEST SCORE**

PRESS KEYPAD **0**

PRESS KEYPAD **YES**

TO CHANGE THE SCORE WHEN A GOAL IS MADE (ie. Home team scores a goal)

PRESS KEYPAD **SET**

PRESS KEYPAD **HOME SCORE**

PRESS KEYPAD **1**

PRESS KEYPAD **YES**

5. PENALTIES

TO ADD PENALTIES

STOP THE CLOCK FROM RUNNING TIME

FLIP THE SWITCH ON THE HAND HELD CONTROL TO **“OFF”**

PRESS KEYPAD **SET**

PRESS KEYPAD **HOME PENALTY** OR **GUEST PENALTY**

{ENTER TIME ie. 2:00 min penalty}

PRESS KEYPAD **0**

PRESS KEYPAD **2**

PRESS KEYPAD **0**

PRESS KEYPAD **0**

PRESS KEYPAD **YES**

IT WILL ASK FOR A PLAYER – YOU MUST ENTER 2 DIGITS (ex. 08)

PRESS KEYPAD **0**

PRESS KEYPAD **8**

PRESS KEYPAD **YES** - Penalty will be displayed

IF ANOTHER PENALTY IS CALLED ON TEAM WITH ONE PLAYER ALREADY IN THE BOX, THEN USE: **HOME PENALTY** OR **GUEST PENALTY**

START THE CLOCK AT THE DROP OF THE PUCK

FLIP THE SWITCH ON THE HAND HELD CONTROL TO **“ON”**

All penalties will clear when penalty time runs out.

TO CLEAR PENALTIES WHEN GOAL IS SCORED DURING POWER PLAY

PRESS KEYPAD **HOME PNLTY** OR **GUEST PNLTY**

PRESS KEYPAD **PNLTY CLEAR**

PRESS KEYPAD **YES**

AT THE END OF EACH PERIOD, THE CLOCK WILL STOP AT 0:00 TIME.

THE HORN WILL CONTINUE TO SOUND UNTIL YOU FLIP THE SWITCH ON THE HAND HELD CONTROL TO **“OFF”**

IN BETWEEN PERIODS – SET TIME TO 1 MINUTE AND START CLOCK. WHEN HORN SOUNDS, RESET TIME TO NEW PERIOD LENGTH.

IF THERE IS STILL TIME LEFT ON A PENALTY IN BETWEEN PERIODS, TURN PENALTY TIME OFF

PRESS KEYPAD **PENALTY ON/OFF**

PRESS KEYPAD **YES**

AFTER 1 MINUTE REST BETWEEN PERIOD, TURN PENALTY TIME ON

PRESS KEYPAD **PENALTY ON/OFF**

PRESS KEYPAD **YES**