

Old Arena

Datronics 4000 Series

Turn the clock on with the toggle switch located in the back.

- If already on skip to “Setting Time”.
- You will see “Resume Game”, press “Clear*No”.
- Enter the numbers 062 - Enter it now, press “Enter*Yes”.
- 1/10 second, press “Clear*No”.

Setting Time

- Press “Set Main Clock”.
- Put in the time you want, for example 1500, press “Enter*Yes”.
- Start and stop the clock with the green “Start” and red “Stop” buttons.

Penalties

- Press “Player•Penalty” then “Enter*Yes”.
- Enter the player jersey number, for example “4” then “Enter*Yes”.
- Enter the penalty time, for example “130” then “Enter*Yes”.

Clearing Penalties

- Press “Player•Penalty”.
- Press the up or down arrow to find the penalty you want to clear.
 - Once you find the penalty you want press “Clear*No” then “Enter*Yes”.

Periods

- Press “Period•” and then the number of the period, for example 1, 2, or 3.
- To advance from one period to the next press “Period+1”.

Scoring

- Advance the score by pressing “Score+1”
- If you make a mistake press the appropriate team’s “Score” button, enter the numeric score you want, and then “Enter*Yes”.

Count Up/Down Button

- Do not press this button ever, if you do or find that the clock is running backwards do this.
 - Press “Count Up/Down”.
 - It will ask “Toggle Clock Direction”
 - Use the up or down arrow to correct then “Enter*Yes”.

Horn

- The horn will automatically sound at the end of the period.
- Manually operate the horn with the yellow “Horn” button.