



General Scoreboard Instructions



1. Turn on scoreboard
2. First, the screen will ask if you want to start where you left off, push **NO**
3. ****The next screen may ask you to enter the model code – enter the model from the device**
4. If it asks if you would like to use shot clocks, push **NO**
5. Would you like to use penalty time out, push **YES**
6. To set the game time push the following:
 - a. SET
 - b. TIME
 - c. Enter your game time (16:00)
 - d. Push YES
 - e. It will ask which period, enter 1, 2, 3
7. To set scores push the following:
 - a. SET
 - b. HOME SCORE
 - c. 0
 - d. YESSame goes for Guest Score.
****Some rinks have +1/-1 for home/guest scores as well**
8. To set penalty minutes push the following:
 - a. SET
 - b. HOME PNLTY
 - c. Enter penalty time (2:00)
 - d. Enter player number when prompted
 - e. Push YESSame goes for Guest Pnlty
9. To clear penalty's, push the following:
 - a. HOME PNLTY or GUEST PNLTY
 - b. PNLTY CLEAR
 - c. It will ask if you want to clear it
 - d. YES

Scoreboards vary from one arena to another, but this general instruction sheet that will get parents started.