ORONO YOUTH HOCKEY ASSOCIATION

TIME CLOCK/SCOREBOARD INSTRUCTIONS

Start by clicking on the Hockey Clock Simulator link:

http://files.leagueathletics.com/Images/Club/8788/HockeyClock/tic.htm

TIME CLOCK INSTRUCTIONS

1. On the north side rink wall there is a cord that hangs down from the time clock. As soon as the zamboni is finished and the teams step on the ice, turn the clock on.

SCOREBOARD INSTRUCTIONS

2. Turn the scoreboard power on; the switch is on the back of the control board. Top left of clock simulator click on power button.
3. Do not continue the previous game, hit the **CLEAR** Button.
4. The code is already registered in the scoreboard so just hit the **ENTER** button.
5. It does not matter if the tenths of a second are on or off, so hit the **ENTER** button.

SETTING GAME TIME

1. Hit the **SET MAIN CLOCK** button.
2. Type in the time and hit the **ENTER** button. . Ex. 5 minutes, type in 5000. (check the display on the scoreboard control)
3. To run the time hit the **START** button, To stop the time hit the **STOP** button.
4. To enter the periods, hit the **PERIOD+** button until you have the desired period on the scoreboard.
5. To reset the time after a period hit the **SET TIME** button and then the **ENTER** button. The previous period time will be entered automatically. If you need to enter a different time length repeat steps 1 & 2 with the new time.

ENTERING PENALTIES

1. Hit the **PLAYER/PENALTY** button.
2. Hit the **ENTER** button.
3. Type in the player number. (will not show on some scoreboards)
4. Hit the **ENTER** button.
5. Type in the penalty time. Ex. A 1:30 penalty, hit 130. (Double check the scoreboard control display)
6. Hit the **ENTER** button.

REMOVING PENALTIES

1. Hit the **PLAYER/PENALTY** button.
2. Hit the **UP ARROW** key until the penalty you need to remove shows on the scoreboard control display.
3. Hit the **CLEAR** button.
4. Hit the **ENTER** button.

PAUSING PENALTIES FOR 1 MINUTE BREAKS BETWEEN PERIODS

1. Hit the **DISABLE PENALTY CLOCK** button.
2. Hit the **SET MAIN CLOCK** button.
3. Type in the time and hit the **ENTER** button. . Ex. 1 minute, type in 1000. (check the display on the scoreboard control)
4. To run the time hit the **START** button. To stop the time hit the **STOP** button.
5. To enter the periods, hit the **PERIOD+** button until you have the desired period on the scoreboard.
6. To reset the time after a period hit the **SET TIME** button and then the **ENTER** button. The previous period time will be entered automatically. If you need to enter a different time length repeat steps 1 & 2 with the new time.

ADDITIONAL TRAINING

Link to uTube Video Instructions: http://www.youtube.com/watch?v=QGl5OBt1SaI